

# How to install Online Updates

These instructions apply to all Selfie Wizards that have the Online Updater installed. This is pre-installed on all units with Version 24 onwards.

You will need:

- The SW powered on, TV/Display is optional.
- The YELLOW Data Cable
- Access to your home/office router
- Install Time: varies but usually just a few minutes


1. Connect the data cable between the SW and your Home/Office router

2. **From a phone:**

- a. Connect to the SW WiFi
- b. In your web browser enter: admin/
- c. Go to: System Update
- d. The screen will show:
  - If you are successfully connected to the internet
  - Your current Software Version
  - If your SW is up to date or if there are updates available.

**OR.. From a Windows PC or Laptop:**

- a. Connect to the SW WiFi
- b. In your web browser enter: selfiewizard/admin/
- c. Go to: System Update Click 'Yes'



**Wait until the SW reboots. The update is then complete.**