

Selfie Ninja

Version: 48

Your Serial Number:

Important information – please read before first use

Use the supplied power adaptor only.

The use of any other power source WILL result in data corruption and permanent damage to the unit and **voids the warranty.**

Support

- **Have you joined the Selfie Wizard Owners Group..?**

For the fastest response to support enquiries, all the latest News, Tips, Tricks and Idea Sharing:

[Facebook.com/groups/SelfieWizard](https://www.facebook.com/groups/SelfieWizard)

Whats in the Kit

- Ninja Print Server
- International Universal Power Supply
- RED Data Plug (required for Printing)
- 2.4ghz External Antenna
- Quick Start Guide

Quick Start

- 1) Connect WiFi Antenna
- 2) Connect Power Adapter to Ninja
- 3) Connect your Phone/iPad to the Ninja Wi-Fi Network

Ninja: WiFi password is: 12345678

- 4) Open a **web browser** on your Phone (Not Google)
To access the admin menu enter: **admin/** OR **10.10.10.10/admin/**
- 5) The Admin Menu provides access to all the features of the unit.

Shut down

Simply turn off/remove power.


Printer Setup

The printing system is pre-loaded with drivers for all compatible Printers.

Each Printer will require one time initial setup. To enable printing the **RED** Data Plug must be inserted and remain attached to the Ninja/Wizard


To install and setup your Printer please follow these instructions carefully

- With the unit switched on, plug in the Printer USB
 - Turn Printer on
 - From the Main Menu select **'Printer Setup' >> 'Printers'**
1. Select **'Add Printer'**




Local Printers: will display the currently connected printer(s) **'Check'** against the printer to set up then click **'Continue'**


2. TIP: Give your Printer a friendly name, description and location. All other settings can be left as they are, then **'Continue'**



3. From the Model list select your Printer Model – then **'Add Printer'**




4. Adjust **Media Size** if required – then **'Set Default Options'**



The printer is now added to the system


5. From the **'Administration'** drop down select **'Set As Server Default'**



6. From the **'Maintenance'** drop down select **'Print Test Page'**

The Printer will now print a Test Page and will be correctly set up

for Automatic Printing



Installed printers will be available as AirPrint Printers to any iOS device connected to the Ninja. No further setup is required to AirPrint.

Common Problems

Not able to connect to Ninja Wifi:

From Startup/Reboot – The most likely cause will be Wi-Fi interference from other equipment in the vicinity. Typically WDMX Uplighters, Radio Microphones, Venue Wi-Fi.

A change of Wi-Fi channels may resolve the problem.

Mid-event – On rare occasions Wi-Fi may become unresponsive or refuse new connections. Reboot the Ninja by removing power. Wait till all lights on the unit have gone out and apply power again.

Selfie Wizard Ltd
Bolnore
Newbridge
Cadnam
Southampton
SO40 2NW
United Kingdom

www.SelfieWizard.com

mail@SelfieWizard.com

Notes:

